

UPDATING or RELOADING FIRMWARE ON THE RECEIVER (R8) UNITS

- You need WINFLASH to do anything with the receivers. **You will need IT to DOWNLOAD AND INSTALL WINFLASH ON YOUR COMPUTER FIRST.** It is located at http://www.trimble.com/trimbler8gnss_ts.asp?Nav=Collection-21462. Select the topmost Winflash Utility from the downloads list and save on your computer so IT can execute it.
- May need to purchase receiver update from Trimble if the warranty is up on the receivers. They will send a password.
- After WINFLASH is installed:
 1. Plug in a 9 pin connector b/w the computer and the receiver
 2. Open WINFLASH and it will take you to the Trimble website. Select your device type, then NEXT.



3. Now select “UPDATE RECEIVER OPTIONS”, NEXT
4. Pick LEGACY PASSWORD and type in or copy and paste your password from the supplier in the “Option Password” box, then NEXT
5. Select FINISH and it will establish a connection to the R8.
6. When it is done, select MENU
7. Now select LOAD GPS SOFTWARE, then NEXT



8. Pick your model (the model is on the back of the receiver), then NEXT
9. Select FINISH and it will load the software.

When it is done, you can select MENU again and scroll down and select “Verify GPS Software Version”. It should be “*software:4.61, Boot:4.11, Radio:4.60u*”