CADD NOTES - Index

Item **NOTE**.*pg(s)*

A

Acres **8**.*2*
Alignments (Roadcalc) **3**.*32*
Annotate (Drafting) **3**.*47*
Annotate, Profile Grid **3**.*30*
Annotation Styles (Drafting) **3**.*47*
AREATABLE **10**
Area table, sample **10**.*3*
Area table, technical information **10**.*3-4*
Arrowheads, change size **8**.*2*

B

Bar scale (Drafting, Insert) **3**.*47*
BSCALE (barscale) **8**.*2*
BORDERS command **6**.*1-2*
Borders, defaults **6**.*4*
Borders, notes **6**.*4*
Borders, plotting **6**.*3*
Borders, standard NRCS **6**

C

Change elevations **3**.*48*
Change layer (CL) **8**.*4*
CHARROWS **8**.*2*
CHOBL **8**.*2*
CHT **8**.*3*
CL (change layer) **8**.*4*
Clip an image **17**.*12*
Colors (related to lineweights) **5**.*3*
Contours (Surface Modeling) **3**.*27*
Coordinate system, set **17**.*2-3*
Copy layer (CPL) **8**.*4*
Convert image/drawing to a different coordinate system **17**.*7-10*
CPL (copy layer) **8**.*4*
Creating an image from AutoCAD **16**
Cross section sheets (Roadcalc) **3**.*39-40*
Cross sections (Roadcalc) **3**.*32-34*

D

Data Collection **3**.*14-16*
Data Connect, images **17**.*5-7*
Data Transfer **3**.*17*

CADD NOTES - Index

Item **NOTE**.*pg(s)*

DOTGRID....**8**.*3*
Downloading data....**3**.*14*
Drafting....**3**.*47-48*
Drawings, plotting....**7**.*6*
Drawings, standard NRCS (MO)....**7**
Drawings, standard (additional)....**15**.*1*
Drawings, technical information....**7**.*9*
Duplicate Nodes list....**3**.*23*

E

Elevations, change....**3**.*48*
Export text (Drafting, Text)....**3**.*48*
Extract, Profile (from TIN, from Entity)....**3**.*29*

F

File format, standard drawings library....**7**.*9*
Freeze layer (LF)....**8**.*4*

G

Georeferenced images....**17**.*1-10*
Grid, DOTGRID....**8**.*3*
Grid, Profile....**3**.*30*

H

HECTARES....**8**.*3*
Help, Iowa How-To sheets....**15**.*1*
How-To sheets (Iowa)....**15**.*1*

I

Image, clip....**17**.*12*
Image, creating from AutoCAD....**16**
Image manager....**17**.*13*
Images, data connect....**17**.*5-7*
Images, georeferenced images....**17**.*1-10*
Images, inserting into AutoCAD....**17**
Images, non-georeferenced images....**17**.*11*
Image transparency....**17**.*12-13*
Import data (Data Transfer)....**3**.*17*
Import text (Drafting, Text)....**3**.*48*
Inserting images into AutoCAD....**17**

CADD NOTES - Index

Item **NOTE**.*pg(s)*

L

Layers, border **6**.*5*
Layer freeze (LF) **8**.*4*
Layers in standard drawings **7**.*8*
Layer make (LM) **8**.*4*
Layers, standard **5**.*4*
Layers, using standard **13**
Layer tools **8**.*4*
LF (layer freeze) **8**.*4*
Library, Process **3**.*7-8*
Line Annotate (Drafting) **3**.*47*
List duplicate nodes **3**.*23*
List nodes (COGO, Reports) **3**.*22*
List nodes (Data Transfer) **3**.*17*
LM (layer make) **8**.*4*

M

Menu structure (Eagle Point) flow chart **1**
Menu structure (Eagle Point) index **2**

N

Node list (Data Transfer) **3**.*17*
Node list (COGO, Reports) **3**.*22*
Node selection (COGO) **3**.*18*
Nodes, place **3**.*19*
Nodes, raise/lower **3**.*21*
Nodes, renumber **3**.*20*
Nodes, swivel **3**.*20*
North arrow (NRCS) **8**.*5*
North arrow (EP Drafting, Insert) **3**.*47*

O

Obliquing angle, change **8**.*2*
Other resources **15**

P

Place Node **3**.*19*
Placement method, borders **6**.*4*
Placement method, standard drawings **7**.*6*
Plan & Profile, Sheets (Roadcalc) **3**.*41-42*
Plotting borders **6**.*3*

CADD NOTES - Index

Item **NOTE**.*pg(s)*

Plotting standard drawings **7**.*6*
Printer, configure **3**.*13*
Process Library **3**.*7-8*
Profile Coordinate System (PCS) **3**.*28*
Profile, Extract (from TIN, from Entity) **3**.*29*
Profile Grid **3**.*30*
Profile sheets (Roadcalc) **3**.*41-42*
Profiles **3**.*28-30*
Profiles (Roadcalc) **3**.*35*
Profile table, sample **11**.*3*
Profile table, technical information **11**.*4*
PROFTABLE **11**
Project manager **3**.*7-8*
Project settings **3**.*8*
Project slopes **3**.*44*
Project, start a new **3**.*7*
Properties, standard **13**

Q

Query elevation (WELEV) **8**.*5*
Query layer (WL) **8**.*4*
Quick start guide **3**

R

Raise/Lower Nodes **3**.*21*
Raster images, inserting into AutoCAD **17**
Renumber Nodes **3**.*20*
Resources, other **15**
Roadcalc **3**.*31-43*

S

Scales, setting horizontal and vertical **3**.*8*
Selecting nodes (COGO) **3**.*18*
Set layer (SL) **8**.*4*
SETTEXT command **5**.*2*
Settings (Eagle Point) **3**.*8*
Site Design **3**.*44-46*
SL (set layer) **8**.*4*
Slope projection (Site Design) **3**.*44*
Soil log annotation **12**
Soil log annotation, file format **12**.*2-3*
Soil log annotation, sample **12**.*4-5*

CADD NOTES - Index

Item **NOTE**.*pg(s)*

SOILLOGS **12**.*1*
Stadia surveys, entering with Eagle Point **14**
Stage-storage table (AREATABLE) **10**
STANDARD command **7**.*1-2*
Standard drawings, defaults **7**.*7*
Standard drawings, technical information **7**.*9*
Standard drawings, additional **15**.2
Standard NRCS drawings (MO) **7**
Standard properties **13**
Standards **5**
STDPROP command (standard properties) **13**
Surfaces, manage (Roadcalc) **3**.*32*
Surface modeling **3**.*24-27*
Surveys (stadia), entering with Eagle Point **14**
Swapspace (CHSPACE) **8**.*3*
Swivel Nodes **3**.*20*

T

TABLE **9**
Table, area/storage **10**
Table, file format **9**.*3-4*
Table, sample file **9**.*4*
Text, change properties **8**.*3*
Text size (setting for Eagle Point) **3**.*8*
Text sizes **5**.*1*
Text standards **5**.*1*
TIN (Surface Modeling) **3**.*26*
Title info, borders **6**.*4*
Toolbox of additional commands **8**
Training website **15**.2
Typical sections (Roadcalc) **3**.*36-37*

U

User data, standard drawings **7**.*7*

V

Volumes (Roadcalc) **3**.*43*
Volumes, between surfaces (Site Design) **3**.*45*

CADD NOTES - Index

Item **NOTE**.*pg(s)*

W

WELEV **8**.*5*
What layer? (WL)) **8**.*4*
WL (what layer?) **8**.*4*

Z

Z9 ..... **8**.*1*