



Natural Resources Conservation Service

CONSERVATION PRACTICE STANDARD

WETLAND RESTORATION

CODE 657

(ac)

DEFINITION

The re-establishment of abiotic conditions (e.g., hydrology, topographic features, and substrate) on partially, effectively, or fully drained wetlands to a close approximation of pre-disturbance abiotic conditions.

PURPOSE

Address identified resource concerns (e.g., water quality degradation, inadequate habitat for wildlife, or degraded plant condition) by restoring the original abiotic conditions to an area that was once an undisturbed and naturally occurring wetland.

CONDITIONS WHERE PRACTICE APPLIES

This practice applies to any land use (i) where there was once a naturally occurring wetland, (ii) the wetland has been altered by onsite actions or offsite actions or disturbances that changed the hydrology and other abiotic features, and (iii) where the conservation objective is to restore the area to a close approximation of the pre-disturbance wetland conditions.

Many disturbed wetlands historically contained a mosaic of landscape features, including some small non-wetlands (e.g., pimple mounds, mima mounds, gilgai uplifts, irregular sediment deposition in floodplains) making it impracticable to separate (delineate) these areas from the historic wetland areas. In such situations, wetland restoration will include intermingled non-wetlands, with the objective of replicating the historic wetland and non-wetland conditions within the project area.

Commonly supporting practices include, but are not limited to:

- Conservation Practice Standard (CPS) Dike or Levee (Code 356) or Diversion (Code 362), used to construct a dike, diversion, berm, or ditch plug.
- CPS Structure for Water Control (Code 587), used to install a water control structure.

Common associated practices installed prior to or following installation of this practice include:

- CPS Wildlife Habitat Planting (Code 420) or Tree and Shrub Establishment (Code 612), used to restore the plant community.
- CPS Critical Area Planting (Code 342), used to plant vegetation on areas expected to have high erosion rates.
- CPS Wetland Wildlife Management (Code 644), used to manage the habitat.
- CPS Shallow Seasonal Water Management for Wildlife (Code 646), used to manage shallow water to mimic natural floodwater pulses.
- CPS Brush Management (Code 314) or Herbaceous Weed Treatment (Code 315), used to control undesirable brush or herbaceous species.

NRCS reviews and periodically updates conservation practice standards. To obtain the current version of this standard, contact your Natural Resources Conservation Service State office or visit the Field Office Technical Guide online by going to the NRCS website at <https://www.nrcs.usda.gov/> and type FOTG in the search field.

USDA is an equal opportunity provider, employer, and lender.

NRCS, NHCP
January 2024

- CPS Forest Stand Improvement (Code 666), used to manage the species composition or density of existing trees.
- CPS Prescribed Burning (Code 338), used to restore or manage the plant community, or for site preparation.
- CPS Prescribed Grazing (Code 528), used to manage the vegetation with livestock.
- CPS Structures for Wildlife (Code 649), used to provide abiotic structures for wildlife (e.g., elevated mounds to provide nesting sites and escape from periods of high water; course woody debris to provide shelter, basking, and foraging habitat; and nest boxes or platforms).

This practice does not apply to:

- Creating a wetland to treat point and non-point sources of water pollution. Use CPS Constructed Wetland (Code 656).
- Rehabilitating a degraded wetland, the reestablishment of a former wetland, or the modification of an existing wetland, where specific wetland functions are augmented beyond the original natural conditions, at the expense of other functions. Use CPS Wetland Enhancement (Code 659).
- Creating wetland functions on a site that was not historically a wetland. Use CPS Wetland Creation (Code 658).

CRITERIA

General Criteria Applicable to All Purposes

The restored wetland will be in the same hydrogeomorphic class and same vegetative modifier as the historic wetland (USDA NRCS 2008).

Evaluate sites that are suspected of containing hazardous material. If confirmed, the practice shall not be installed.

Identify the project area physical and legal constraints (e.g., property boundaries, flood prevention levees, public drainage systems, and changes in the watershed) to determine practice feasibility and scope.

Within the physical and legal constraints, and to the extent practicable, restore hydrology (frequency, duration, depth, and timing of inundation or saturation), source (e.g., groundwater discharge, overbank flooding, or tidal inundation), and hydrologic losses (e.g., evaporation, vegetative transpiration, groundwater recharge, and surface outflow) to the historic conditions by:

- Removing sediment or fill.
- Breaking or crushing drainage tile.
- Breaching or removing berms, dikes, terraces, and levees.
- Filling pits or ponds.
- Grading to re-establish macro- or micro-topography.
- Installing berms or dikes with the application of CPS Code 356.
- Installing diversions with the application of CPS Code 362.
- Installing structures for water control with the application of CPS Code 587.
- Managing frequency, depth, duration, and timing of inundation with the application of CPS Shallow Seasonal Water Management for Wildlife (Code 646) to mimic natural and historic flood pulses.

CONSIDERATIONS

[General Considerations]

Restoring wetland hydrology to an area may increase or decrease the hydrology to adjacent and downgradient areas, including adjacent wetlands.

Some current streams and adjacent areas were historically low-gradient wetlands (Cluer and Thorne 2014). Soil investigations often provide strong evidence of the pre-disturbed conditions.

Excessive excavating and grading activities have the potential to significantly disrupt soil profiles and facilitate the establishment of noxious and invasive plant species.

Wetlands attract many species of wildlife. Some can create safety concerns with adjacent roads, airports and military installations, which may introduce liability concerns to the agency and landowner.

Restoring the occurrence of elevated areas with lighter textured soils (e.g., sand, sandy loams) removed during previous land-clearing, leveling, and plowing activities, will restore the plant species diversity and subsurface nesting sites for an array of small mammals, reptiles, and invertebrates.

PLANS AND SPECIFICATIONS

Where applicable, assure water rights support the restoration objectives.

Describe the past actions that impacted the project area.

Describe and contrast the historic conditions and current conditions for soils (e.g., presence of aquitards, wetting and drying cycles), hydrology (e.g., source and hydroperiods) and vegetation (e.g., species composition, structure, and distribution) associated with the hydrology described. Extrapolate the historic conditions from a review of aerial photography or other remotely sensed data, soil maps, topographic maps, stream gage data, similar intact reference wetlands, and historical ecological records.

Describe the target hydrological conditions and provide an analysis of alternatives that compares different restoration actions and associated water management actions over the project life. Document alternatives considered with clear support for the chosen alternative.

Include a plan view, quantities, and sufficient profiles and cross-sections to define the location, line, and grade for stakeout, and checkout.

Identify suitable water sources based on groundwater investigations, stream gage data, water budgeting, or other appropriate means.

Identify annual water management practices to be implemented following restoration of the wetland. (e.g., CPS Seasonal Water Management for Wildlife (Code 646)).

OPERATION AND MAINTENANCE

Operation and Maintenance (O&M) activities may be needed to ensure the continued hydrologic function of the restored wetland. If needed, a monitoring schedule will be included in the O&M plan.

The O&M plan may include the following:

- Maintenance requirements for water control structures, or other structural practices critical to maintaining the target conditions.
- Maintenance related to sedimentation.

REFERENCES

Cluer, B., and C. Thorne. 2014. A Stream Evolution Model Integrating Habitat and Ecosystem Benefits. *River Research and Applications*, 30(2) 135-154.

Maschhoff, Justin T & James H. Dooley. 2003. Functional Requirements and Design Parameters for Restocking Coarse Woody Features in Restored and Enhanced Wetlands.

USDA, NRCS. 2008. Hydrogeomorphic Wetland Classification System: An Overview and Modification to Better Meet the Need of the Natural Resources Conservation Service. Technical Note No. 190-8-76. February.

USDA, NRCS. 2011. Scenarios for Wetland Restoration. Technical Note No. 4. October .

USDA, NRCS. 2021. Wetland Restoration, Enhancement, or Creation, Engineering Field Handbook Part 650, Chapter 13. 160 pp.