



HOLES DRILLED AT A SLIGHT ANGLE AND EPOXIED INTO EXISTING SLAB, MATCHING PLANNED BAR SIZE AND SPACING

SLABS



WALLS



ELEVATION VIEW

NOTES

1. DRILL HOLES, THE SAME DIAMETER AS THE BARS, INTO EXISTING CONCRETE. DRILL AT A SLIGHT ANGLE AT SPACING OF REBAR IN NEW CONCRETE. DUST NEEDS TO BE REMOVED.
2. POUR EPOXY INTO HOLES AND POUND REBAR INTO PLACE. **NOTE:** IF PASTE EPOXY IS USED, HOLES MAY BE DRILLED HORIZONTAL. APPLY PASTE EPOXY TO BARS BEFORE INSERTING THEM INTO HOLES.
3. BEND REBAR TO HORIZONTAL AND TIE NEW REBAR TO THEM.



United States
Department of
Agriculture

Natural Resources
Conservation Service

NON LIQUID-TIGHT CONNECTION
TO EXISTING CONCRETE

CLIENT: _____
COUNTY: _____

Designed _____	Date _____
Drawn _____	Date _____
Checked _____	Date _____
Approved _____	Date _____

File Name WI-550
Date 07/14
Sheet of