



## SECTION VIEW OF SLAB

**NOTES**

1. DRILL HOLES, THE SAME DIAMETER AS THE BARS, INTO EXISTING CONCRETE. DRILL AT A SLIGHT ANGLE AT SPACING OF REBAR IN NEW CONCRETE. DUST NEEDS TO BE REMOVED.
2. POUR EPOXY INTO HOLES AND POUND REBAR INTO PLACE. NOTE: IF PASTE EPOXY IS USED, HOLES MAY BE DRILLED HORIZONTAL. APPLY PASTE EPOXY TO BARS BEFORE INSERTING THEM INTO HOLES.
3. USE DRAWING WI-501 FOR PROPER USE OF EXPANSIVE WATERSTOP MATERIALS
4. BEND REBAR TO HORIZONTAL AND TIE NEW REBAR TO THEM.



United States  
Department of  
Agriculture

Natural Resources  
Conservation Service

**FEED STORAGE AREA  
ATTACHING NEW TO EXISTING CONCRETE**

CLIENT: \_\_\_\_\_

COUNTY: \_\_\_\_\_

	Date
Designed _____	_____
Drawn _____	_____
Checked _____	_____
Approved _____	_____

File Name WI-901
Date 08/14
Sheet of